UNINET iColor

Cartridge Replacement Guide

iColor 540
iColor 550
iColor 560

Standard Printing




Spot Color Overprinting



Printer Display Reads	Replace with
Cyan low/out/empty	Cyan
Magenta low/out/empty	Magenta
Yellow low/out/empty	Yellow
Black low/out/empty	Black/White/Clear

Printer Display Reads	Replace with
Cyan low/out/empty	White/Clear
Magenta low/out/empty	Magenta
Yellow low/out/empty	Yellow
Black low/out/empty	Cyan

Spot Color Underprinting



iColor 500
iColor 600

Underprint

Printer Display Reads	Replace with
Cyan low/out/empty	Cyan
Magenta low/out/empty	Magenta
Yellow low/out/empty	Yellow
Black low/out/empty	Black/White/Clear



For Underprinting white.
Typically used for right side reading applications like printing color on clear or dark medias

Overprint

Printer Display Reads	Replace with
Cyan low/out/empty	Black/White/Clear
Magenta low/out/empty	Magenta
Yellow low/out/empty	Yellow
Black low/out/empty	Cyan




For Overprinting white.
Typically used for garment decoration.


iColor 650

WARNING Replace with UNINET OEM supplies only! Incompatible supplies will damage the printer.

Standard Printing



Spot Color Underprinting




Spot Color Overprinting



Printer Display Reads	Replace with
Cyan low/out/empty	Cyan
Magenta low/out/empty	Magenta
Yellow low/out/empty	Yellow
Black low/out/empty	Black/White/Clear

Printer Display Reads	Replace with
Cyan low/out/empty	White/Clear
Magenta low/out/empty	Magenta
Yellow low/out/empty	Yellow
Black low/out/empty	Cyan

iColor 800W



Printer Display Reads	Replace with
Cyan low/out/empty	Cyan
Magenta low/out/empty	Magenta
Yellow low/out/empty	White
Black low/out/empty	Yellow

WARNING **Replace with UniNet OEM supplies only!**
Incompatible supplies will damage the printer.